

A&N Model Trucks



Aussie T610 regular truck.
Resin kit, 1/24

Warning!

For the best results we highly suggest to use our photo-etched chassis for Aussie T610 trucks. But you still can use an Italeri's generic American chassis (except Volvo VN and Peterbilts).

Read carefully this instruction and please follow it during assembling, otherwise you could face problems with assembling the model.

Photo-etched parts have sharp edges, please be careful.


This model kit contains very small parts and is **not suitable for children**.


This model kit is for advanced modellers only!

You can download this instruction as PDF-file at the our site at «Instructions» section, or use QR-code on the last page.

Symbols:


 - glue parts;


 - do not glue parts;

 - bend parts;

 - attention;

 - moving parts;

 - your choice;

 - cut;

! Basic guidelines for modification of Italeri's chassis


(skip this section and jump on page 5 if you use photo-etched chassis).

WARNING! We didn't test our cab kits with Italeri chassis, we can provide only basic dimensions for chassis.


1. Frame length.




2. Wheelbase and space between center of front wheels and front end of a frame



3. Dimensions for front suspension.




4. Dimensions for cab's supports (from front end of frame).




5. Max height of radiator.



6. How to make cross-member for rear cab's support.




7. Space from front end of frame and front ends of tanks.




8. Front end of frame.

8.1. 





8.2. 




PE-part #39

8.3. 




! Holes' numbers you can find on a paper sheet in our chassis kit.
! In case if you use Italeri chassis kit as donor, please refer previous section for dimensions.


Main section




16. 




17. 





18. 




19. 



20. 




21.  x2




22.  x2




23.  x2




24.  x2




25. 



26. 




27. 



28.  x2




29. 




Aussie T610 SAR truck. Resin kit, 1/24


30. 




31.  x2





32.  x2



33.  x2




34.  x6




PE-part #22

35.  x6




36.  x2




PE-part #23


37.  x2




38. 




39. 




40. 





41.  x2



42.  x2




43.  x2




PE-part#9

44.  x2



45.  x2





Aussie T610 SAR truck. Resin kit, 1/24


46.  x2



47. 




48.  x2




49.  x2


PE-part #10




50.  x2




51. 




52. 



53.  x2



54.  x2



55. 




PE-parts
#17, 18


56.  x2




57. 




58. 




59.  x2




60. 




61. 




62. 




63. 




64. 




65. 





66.  x2




67.  x2




68.  





69. 




70.  x2




71.  




72. 




73.  x2




74. 



75.  x2




76.  x2




Aussie T610 SAR truck. Resin kit, 1/24

77.  x2




78.  x2


PE-part #21



79. 




80.  x2




PE-part #36


81.  x2



82. 




83. 




bolt

84. 




85. 




PE-part #25

86. 




bolt

87. 




PE-part #26

88. 




89.  x2



Aussie T610 SAR truck. Resin kit, 1/24

90. 🖱




91. 🖱 x5



92. 🖱 x2




93. 🖱




94. 🖱


PE parts #49




95. 🖱



96. 🖱




97. 🖱 x2




98. 🖱 x2




99. 🖱 x2




100. 🖱 x2




101. 🖱




102. ✂



103. 🖱



104.




Aussie T610 SAR truck. Resin kit, 1/24

120. x8



Place styrene inserts into a tanks.


121. x6




122. x2




123. x8




124. x1




125. x8




126. x8




127. x1



128. x1




129. x1



130. x3




131. x1



!

Use battery box (frames 106-112) for leveling steps


132. x1




133. x3



134. x1




135. 




Repeat steps
124-132 for
right side.


136.  x2




137. 





138. 





139. 




140. 




141. 




142.  x2



143.  x2



144. 



145. 

